# Ajay Kumar Garg Engineering College, Ghaziabad

## Department of ECE

#### Sessional Test-2

Course:

B.Tech

2017-18

Session: Subject:

Optical Instrumentation

Max Marks: 50

Semester: VI

Section: EI-K

Sub. Code: NIC-031

Time:

2 hour

## Section-A

A. Attempt all the parts.

Note: Answer all the sections.

(5x2 = 10)

1. What is an Optical Detector?

Ans: A device used to detect or measure light or other electromagnetic energy is called Optical detector.

2. What is direct and Indirect band gap energy?

Ans: - The band gap is called direct of the momentum of electrons is same in both CB and VB. In Indirect gap a photon cannot be emilted because the electron must pass through an intermideate state.

3. How data can be stored optically?

Ans: - There are two sections: - Read section & White section.

And main components were (i) Laser source (ii) Modulator (iii) Beam splitter (IV) Mirror (V) Hologram.

4. What is the phenomenon of Total Internal Reflection?
Ans: If the incident angle is greater than the critical rangle, the wave cannot pass and here is

entirely reflected.

6. Construct a ruby laser. -XENON FLASH LAMP PARTIALLY SILVERED MIRROR RUBY ROD SILVERED BERM FIG: RUBY LASER

6. Name defferent type of LED structures. Explain any one of them with proper diagram.

Ans: There are two types of NED structures: -(i) Surface emitter LEDs and (ii) Edge emitter LEDs.

Surface emilter LEDs


A method for obtaining high radiance is to restrict the emission to a small raction region within the device, The technique was to use an etched well in a Grass substrate en order to prevent heavy absorption of the emitted radiation and to accomodate the fibre. These structures have a low thermal impedance in the active region allowing high current densities and giving high-radiance emission into the optical fiber.

The structure of a high-radiance elched well DH surface emitter for the 0.2 to 0.9 µm wavelength band is shown in figure. The internal absorption in this ducie is very low idue to the larger bandgap confining layers, and the reflection to efficient at the back crystal face is high giving good forward radiance. The emission from the active layer is essentially isotropic, although the celevral emission distribution may be donsidered hambertian with a beam width of 120° due to refraction from a high to a low refr-

ractive index at the GaAs-fiber interface. The power coupled Pe into a multimode step index fiber may be estimated from the relationship:

Pc = T (1-2) ARO (NA)2

where is the Fresnel reflection co-efficient at the fiber surface, A is the smaller of the fiber core cross-section or the emission area of the source and Rp is the radiance of the source.



Ans:- It is npip or prin photodiode. Here is p-region or an n-region is further added and sandwiched between

mi or p-i regions respectively.

Working > When the primary electron hole pairs (EHP) generated by incident photons pass through this extra added region, they get accelerates and acquire so much kinetic energy that they ionize the bound electrons in the tealence kand upon vollesion and in the process create suondary electron hole pairs. This phenomenon is known as impact ionization. If the field is high enough, the secondary carrier pairs may also gain sufficient energy to create new pairs.

This is known as accalanche effect. Thus the carrier get multiplied, all of which contribute to the photo current.

Rectrue field,

P

Gain region


i(n)

Absorption region

It is composed of a lightly doped p-type intrinsic layer deposited on a pt substrate. A normal p-type diffusion is made in the intrinsic layer which is followed by the construction of an not layer such a configuration is called pt npn reach through structure. When the applied reverse beased voltage is low, most of the potential drop is across the p-st junction. As the bais nollage is increased, the depletion layer widers and the latter just reaches through to the The region when the electric field at the p-n junction becomes sufficient for impact ionization. Normally, an RAPD is operated in a fully depleted mode. The photons enter the device through the p+ layer and are absorbed en the intrinsie The region. The absorbed photons create primary EHPs, which are seprated by the electric field en this region. These carriers drift to the p'n region where a strong electric field exists. It is the region where carriers are multiplied first by imapet conization and then by Aualanche breakdown.


Ans: If the plane of recording medium be the 2=0 plane. Let the point object kee set a distance it from the recording medium and be lying on the z-axis. If the reference wave is encident at an angle o to the object wave it is known as OFF-Axis holography and if the reference wave is incident partlel to the object wave, i.e. 0=0, it is known as ON-axis holography. In OFF-Axis holography 070, therefore there is no change in the equation. Therefore, for transmitted wave

 $\begin{aligned} \mathcal{Y}_{t}(n,y) &= \mathcal{Y}_{t}(n,y) \ T(n,y) \\ &= A_{t} e^{ik_{0}n\sin\theta} \left[ \frac{A_{0}^{2}}{d^{2}} + A_{t}^{2} + \frac{2A_{t}A_{0}}{d} \exp{-i\left[k_{0}d - k_{0}n\sin\theta\right]} \right] \\ &+ \frac{k_{0}}{2d} \left(n^{2} + y^{2}\right) \end{aligned}$ 



In ON-Axis holography,  $\theta=0$ , therefore the transmitted wave now will be

$$\begin{aligned} \Psi_{\ell}\left(n,y\right) &= \Psi_{\ell}\left(n,y\right) T\left(n,y\right) \\ &= A_{\ell}\left(\frac{A_{0}}{d^{2}} + A_{\ell}^{2}\right) + \frac{A_{\ell}^{2}A_{0}}{d} \exp\left(-i\frac{k_{0}a}{d}\right) \exp\left[-i\frac{k_{0}}{2d}\left(n^{2} + y^{2}\right)\right] + \\ &\frac{A_{\ell}^{2}A_{0}}{d} \exp\left(+ik_{0}a\right) \exp\left[\frac{ik_{0}}{2d}\left(n^{2} + y^{2}\right)\right] \end{aligned}$$



ON-AXIS

9. An ideal photo-diode has an area of 1x1 cm rand is illisminated by monochromatic light with a wavelingth of 780 mm and with a power density of 1000 W/m². At 300 K, the open circuit voltage is 0.683 V. What is its reverse saluration scurrent, Is?

Am: Ideal photo diode has  $\eta = 10\%$ .

Area = 1×1 Cm

For an ideal pholodiode, the shunt resistence is infinite so that the shunt current is zero. Since leakage current under reverse beas is small Iout I Joe = Io Alg

Substituting

In A = 0.01 Watt and \ = 900 mm, Iout = 7.2 m A

Using  $J_{opt} = 7.2 \text{mA}$ ,  $J_s = 10 \text{nA}$  and T = 300 $N_p = 0.347 \text{ V}$ . 10. A fiber opter gyroscope has a circular coil of dea metal 12 cm. The total length of the fiber used in the coil is 400 m. It it is operating at  $\lambda = 0.633 \, \mu m$ , what is the phase shift corresponding to the rangular speed of 5 x 10 4 rad/s?

Ans

$$\Delta 8 = \frac{2\pi LDR}{cA}$$

Here  $h = 400 \, \text{m}$ ,  $\theta = 12 \, \text{cm} = 0.12 \, \text{m}$ ,  $\Omega = 5 \times 10^4 \, \text{rad/s}$  $\lambda = 0.633 \, \mu \, \text{m} = 0.633 \times 10^6 \, \text{m}$ ,  $\alpha = 3 \times 10^8 \, \text{m/s}$ 

 $\Delta \theta = \frac{2 \times 3.14 \times 400 \times 0.12 \times 5 \times 10^{4}}{3 \times 10^{8} \times 0.633 \times 10^{6}}$  $= 79.36 \times 10^{5} \text{ rad}.$ 

s ar in the

11. What is the role of He atom in He-Ne laser? Explain with the help of energy lucel diagram. Why is it necessary to use a narrow tube?

Ans: - Helium Neon haser is a four luce laser. The Schemeter of a typical Hz-Ne laser is shown. It consits of a long distance tuke of length about 50 cm and diameter I cm. The tube contains a mixture of about 10 parts of helium and I part of neon rat a low pressure. At both ends of the tube are fitted optically plane and partlet mirrors, one of them being only partially silvered. The spacing of the mirrors is equal to an integral number of half-wavelengths of the laser light. In this population inversion is achieved by electric idischarge. In electric idischarge is produced in the gas by means by electrodes outside, the luke connected to a source of high-frequency alternating

The energy level deagram of He-Ne laser is shown in figure. When a power is switched on, the electrony from the discharge collide and 'pump' the He and Ne catoms to melabable states 20.61 eV and 20.66 eV resp above their iground states. Some of the excited He atoms transfer


their energy to ground state Ne atoms in collections. Thus the purpose of He atom is to help in achieving a population inversion in the Ne atoms.

Hestate Collision

Metastable
state

Electron

Impact



When an excited Ne alom passes, from the melastable state at 20.66 eV to an excited state 2 18.70 eV, and it emits a photon of wavelength 6328 A. This photon it emits through the gas meature, and if it is moving parelled to the axis of the lube, is reflected back and forth by the mirror-ends untill it is moving parelled stimuled an excited Ne atom rand causes it to emit a fresh 6328 A photon is phase with the slimulating photon This stimulated transition from 20.66 eV level to 18.70 eV level is the laser transition.

This process is continued and when a beam of Coherent radiation becomes sufficiently intense, a position of it escapes through the partially silvered end.

The Ne atom passes from the 18.70eV lend, spontaneously to a lower melastable state emilling in coherent light, and finally the Ne atom comes down to the ground state through collision with the tube walls. This radiation from lower melastable state to the ground state is radiation less transition.

In He Ne laser, the laser transition closs not terminate out the ground luce, hence the power needed for excitation is less than that in a three-luce laser.


12. Explain how a hologram is recorded and holographic image is reconstructed from it, with the help of proper diagram.

Ans. - Holography is a method in which not only amplitude but also the phase of the light wave is recorded.

The basic lichnique of holography has two sections

(1) Recording of the hologram

(ii) Reconstruction of the 3D image from the photographer plate.




A pholographic plate is exposed simultaneously to waves of light scattered by the 'object' and to the waves of light from a refrence source. The refrence beam is shown here as a plane partlel beam, and is derived from the same light source which illuminates the object.

Because of their high degree of mutual coherence the two sets of waves produce an intrefrence pattern on the plate, which is recorded in the photographic emulsion and forms a hologram.

Let Object wave be  $\varphi_o(n,y) = A_o(n,y) e^{-i\theta_o(n,y)}$ 

and refrence wave  $Y_r(n,y) = Ar(n,y) \in ilr(n,y)$ 

Resultant intensity distribution be  $I(u,y) = | \Psi_0(u,y) + \Psi_1(u,y)|^2$   $= A_0^2 + A_1^2 + A_1 A_0 e^{i(\theta_0 - \theta_1)} + A_2 A_0 e^{i(\theta_0 - \theta_1)}$   $= A_0^2 + A_1^2 + 2A_2 A_0 (as (\theta_0 - \theta_1))$ 



# Reconstructing the 3-D Image

The photographic plate is processed and illuminated with only the reference beam present as shown. Most of the light from the reference beam passes straight through the hologram. Some of it is difficulted by the interference pattern in the emulsion. By the normal diffraction grating equation, light of wavelength A will experience constructive interfrence fortness at englis such that  $\lambda = D Sino$ , where D is the local fringe spacing of the interfrence fringes whose exact shape and distribution depends on the shape of the object and the wavefronts reflected from it. Thus the constructure enterference of these diffrated waves reconstructs the original wavefronts from the object and to an observer the wantfronts appear to be coming from the object itself These wavefronts consitute what is termed as virtual i'mage".

Just as diffraction grating quies diffracted orders on either side of the straight through position, the hologram generals a second image, this image which is usually inferior in quality to the virtual image, is called the real image.